

Strings.ie T1 Digital Tuner Instructions Manual



Thank you for purchasing the T1 digital Tuner. We hope you find the tuner to be an excellent tool which will provide you with years of service. You'll be delighted to know that this tuner comes with a two year guarantee (see below for further details).

Instructions for use

Press the On/Off button to turn the tuner on & off.

Press the Mode button to change the operating mode. The default mode is 'C'. The modes are designed for different instruments and operations. These are as follows:

- C = Chromatic Mode
- G = Guitar
- B = Bass Guitar
- V = Violin
- U = Ukulele

As this is a clip-on tuner it needs to be clipped to the instrument to operate as it uses vibration to pick up any tones. We recommend you clip the tuner to the head of an instrument.

The digital display will show a meter reading which will be centred when the correct pitch is reached. The display will also show you the current note. The display changes colour from Orange to Blue once you are in tune. If the meter is to the left you are flat and if the meter is to the right you are sharp.

Warnings

Do not disassemble, repair or reconfigure the tuner

Make sure the battery (CR2032) is correctly installed. Do not place near a heat source or dispose of in a fire.

Keep the tuner out of direct sunlight or away from heat sources.

Keep away from water or dampness.

Use only a dry cloth for cleaning.

Remove the battery when the tuner is not in use for long periods.

Guarantee

The T1 Tuner comes with a two year guarantee. If the tuner fails simply contact us via www.strings.ie. We will ask you to return the tuner to us and a replacement will be sent to you. It is vital that you contact us before sending a faulty T1 tuner back to us.

Troubleshooting

If the tuner becomes unresponsive or the display is dim please change the battery. The tuner requires a CR2032.

Specifications

- Fully Chromatic

- Direct contact pick-up via clip-on mechanism. Not affected by background noise.
- Orange back light display, turns Blue when in tune.
- Tuning range: C0 (16.35Hz) to A7 (3520.HZ)
- Accuracy: less than 1 cent.
- Powered by 1x CR2032 battery (supplied)
- Dimensions: 58mm High / 31mm Wide / 43mm Deep
- Exclusive Strings.ie 2 year no hassle guarantee

We hope you enjoy using the T1 Tuner.



www.Strings.ie